

Onan

Parts Manual 4.0BFA GenSet

UTILITY VEHICLE




Onan Service Parts

965-0262
1-88 (SPEC C,D)
Replaces
12-84 (SPEC C)
Printed in U.S.A.

General Information

For parts or service, contact the dealer from whom you purchased this equipment or refer to your Nearest Authorized Onan Parts and Service Center.

To avoid errors or delay in filling your parts order, always give the MODEL, SPEC NO. and SERIAL NO. from the Onan nameplate.

A rectangular template for an Onan nameplate. It features the Onan logo at the top. Below the logo is a large rectangular box for the model and specification number. Below that is a smaller rectangular box for the serial number, preceded by the text "SERIAL NO.". The template has two circular holes at the top corners and a tab at the bottom right.

Onan

MODEL AND SPEC NO.

SERIAL NO.

M-1149

For handy reference, insert "YOUR" nameplate information in the spaces above.

Important Safety Precautions

Read and observe these safety precautions when using or working on electric generators, engines and related equipment. Also read and follow the literature provided with the equipment.

Proper operation and maintenance are critical to performance and safety. Electricity, fuel, exhaust, moving parts and batteries present hazards that can cause severe personal injury or death.

FUEL, ENGINE OIL, AND FUMES ARE FLAMMABLE AND TOXIC

Fire, explosion, and personal injury can result from improper practices.

- Used engine oil, and benzene and lead, found in some gasoline, have been identified by government agencies as causing cancer or reproductive toxicity. When checking, draining or adding fuel or oil, do not ingest, breathe the fumes, or contact gasoline or used oil.
- Do not fill tanks with engine running. Do not smoke around the area. Wipe up oil or fuel spills. Do not leave rags in engine compartment or on equipment. Keep this and surrounding area clean.
- Inspect fuel system before each operation and periodically while running.
- Equip fuel supply with a positive fuel shutoff.
- Do not store or transport equipment with fuel in tank.
- Keep an ABC-rated fire extinguisher available near equipment and adjacent areas for use on all types of fires except alcohol.
- Unless provided with equipment or noted otherwise in installation manual, fuel lines must be copper or steel, secured, free of leaks and separated or shielded from electrical wiring.
- Use approved, non-conductive flexible fuel hose for fuel connections. Do not use copper tubing as a flexible connection. It will work-harden and break.

EXHAUST GAS IS DEADLY

- Engine exhaust contains carbon monoxide (CO), an odorless, invisible, poisonous gas. Learn the symptoms of CO poisoning.
- Never sleep in a vessel, vehicle, or room with a genset or engine running unless the area is equipped with an operating CO detector with an audible alarm.
- Each time the engine or genset is started, or at least every day, thoroughly inspect the exhaust system. Shut down the unit and repair leaks immediately.

- Warning: Engine exhaust is known to the State of California to cause cancer, birth defects and other reproductive harm.

Make sure exhaust is properly ventilated.

- Vessel bilge must have an operating power exhaust.
- Vehicle exhaust system must extend beyond vehicle perimeter and not near windows, doors or vents.
- Do not use engine or genset cooling air to heat an area.
- Do not operate engine/genset in enclosed area without ample fresh air ventilation.
- Expel exhaust away from enclosed, sheltered, or occupied areas.
- Make sure exhaust system components are securely fastened and not warped.

MOVING PARTS CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Do not remove any guards or covers with the equipment running.
- Keep hands, clothing, hair, and jewelry away from moving parts.
- Before performing any maintenance, disconnect battery (negative [-] cable first) to prevent accidental starting.
- Make sure fasteners and joints are secure. Tighten supports and clamps, keep guards in position over fans, drive belts, etc.
- If adjustments must be made while equipment is running, use extreme caution around hot manifolds and moving parts, etc. Wear safety glasses and protective clothing.

BATTERY GAS IS EXPLOSIVE

- Wear safety glasses and do not smoke while servicing batteries.
- Always disconnect battery negative (-) lead first and reconnect it last. Make sure you connect battery correctly. A direct short across battery terminals can cause an explosion. Do not smoke while servicing batteries. Hydrogen gas given off during charging is explosive.
- Do not disconnect or connect battery cables if fuel vapors are present. Ventilate the area thoroughly.

DO NOT OPERATE IN FLAMMABLE AND EXPLOSIVE ENVIRONMENTS

Flammable vapor can be ignited by equipment operation or cause a diesel engine to overspeed and become difficult to stop, resulting in possible fire, explosion, severe personal injury and death. **Do not operate diesel equipment where a flammable vapor environment can be created by fuel spill, leak, etc., unless equipped with an automatic safety device to block the air intake and stop the engine.**

HOT COOLANT CAN CAUSE SEVERE PERSONAL INJURY

- Hot coolant is under pressure. Do not loosen the coolant pressure cap while the engine is hot. Let the engine cool before opening the pressure cap.

ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Do not service control panel or engine with unit running. High voltages are present. Work that must be done while unit is running should be done only by qualified service personnel.
- Do not connect the generator set to the public utility or to any other electrical power system. Electrocutation can occur at a remote site where line or equipment repairs are being made. An approved transfer switch must be used if more than one power source is connected.
- Disconnect starting battery (negative [-] cable first) before removing protective shields or touching electrical equipment. Use insulative mats placed on dry wood platforms. Do not wear jewelry, damp clothing or allow skin surface to be damp when handling electrical equipment.
- Use insulated tools. Do not tamper with interlocks.
- Follow all applicable state and local electrical codes. Have all electrical installations performed by a qualified licensed electrician. Tag open switches to avoid accidental closure.
- With transfer switches, keep cabinet closed and locked. Only authorized personnel should have cabinet or operational keys. Due to serious shock hazard from high voltages within cabinet, all service and adjustments must be performed by an electrician or authorized service representative.

If the cabinet must be opened for any reason:

1. Move genset operation switch or Stop/Auto/Handcrank switch (whichever applies) to Stop.
2. Disconnect genset batteries (negative [-] lead first).
3. Remove AC power to automatic transfer switch. If instructions require otherwise, use extreme caution due to shock hazard.

MEDIUM VOLTAGE GENERATOR SETS (601V TO 15kV)

- Medium voltage acts differently than low voltage. Special equipment and training are required to work on or around medium voltage equipment. Operation and maintenance must be done only by persons trained and qualified to work on such devices. Improper use or procedures will result in severe personal injury or death.
- Do not work on energized equipment. Unauthorized personnel must not be permitted near energized equipment. Induced voltage remains even after equipment is disconnected from the power source. Plan maintenance with authorized personnel so equipment can be de-energized and safely grounded.

GENERAL SAFETY PRECAUTIONS

- Do not work on equipment when mentally or physically fatigued or after consuming alcohol or drugs.
- Carefully follow all applicable local, state and federal codes.
- Never step on equipment (as when entering or leaving the engine compartment). It can stress and break unit components, possibly resulting in dangerous operating conditions from leaking fuel, leaking exhaust fumes, etc.
- Keep equipment and area clean. Oil, grease, dirt, or stowed gear can cause fire or damage equipment by restricting airflow.
- Equipment owners and operators are solely responsible for operating equipment safely. Contact your authorized Onan/Cummins dealer or distributor for more information.

KEEP THIS DOCUMENT NEAR EQUIPMENT FOR EASY REFERENCE.

Index

Adapter, Air Duct 14
Adapter, Carburetor - LP 14
Armature, Generator 24,26

Base, Oil 12
Bearing, Camshaft 4
Bearing, Crankshaft 4
Block, Brush - Generator 24,26
Block, Cylinder 4
Block, Terminal 28
Box, Breaker 20,21
Bracket, Exhaust 23
Bracket, Governor 20
Breaker, Circuit 28
Brush, Generator 24,26

Carburetor, Gasoline 14,16
Carburetor, LP 14
Carburetor Components (Gaso) 18,19
Clamp, Muffler 22,23
Coil, Ignition 20
Control, Generator 28,30
Cover, Air Cleaner 14,16
Cover, Breather 4
Cover, Control 28
Cover, Valve 4
Crankshaft 7
Cushion, Vibration 12

Duct, Air Cleaner 14

Element, Air Cleaner 14,16

Filter, Breather Tube 14,16
Filter, Oil 11
Flywheel 7
Fuse, 5 Amp, 10 Amp 28

Gasket, Exhaust Manifold 22,23
Gearcase 9
Generator 24,26
Governor 10
Guard, Scroll 13
Guide, Valve 4

Harness, Wiring 24,26,28
Harness, Wiring - Remote 28
Head, Cylinder 4
Housing, Air 13
Housing, Air Cleaner 17
Housing, Choke 14,16

Kit, Carburetor Repair 18,19
Kit, Gasket 4
Kit, Tune-Up 21

Line, Fuel - Gasoline 14,16

Manifold, Exhaust 22,23
Manifold, Intake 14,16
Muffler, Spark Arrestor 22,23

Paint 31
Piston 8
Plug, Spark 20
Points, Ignition 21
Pump, Fuel - Electric 14,16
Pump, Oil 11

Relay, Start Solenoid 28,30
Resistor, Fixed 24,26
Ring, Piston 8
Rod, Connecting 8
Rod, Governor 10

Seal, Oil - Crankshaft 4,9
Seat, Valve 4
Shield, Heat - Exhaust 23
Solenoid, Start 28
Spring, Governor 10
Stator, Generator 24,26
Strap, Ground 12
Switch, Ignition 28
Switch, Pressure - Oil 11
Switch, Rocker - Control 28

Tappet, Valve 4
Tube, Breather 14,16
Tube, Exhaust 23

Valve, Exhaust 4
Valve, Intake 4

Introduction

This Catalog applies to the BFA Utility Vehicles Generator Set. Parts are arranged in groups of related items. Each illustrated part is identified by a reference number corresponding to the same reference number in the parts list for that group. Parts illustrations are typical. Using the Model and Spec No. from the nameplate, select Parts that apply to your Model and Spec No. Unless otherwise mentioned in the description, parts are interchangeable between models. Right and left sides are determined by facing the engine end (front) of the set.


Engine Data Table

Model and Specification Number	Volts	Parts Key Number
4.0 BFA-3CR/15000C	120/240	1
4.0 BFA-1R/19486C	120	2
4.0 BFA-1R/19486D	120	3
4.0 BFA-3CR/20275C	120/240	4
4.0 BFA-5DR/22540C	120/240	5
4.0 BFA-5DR/22541C	120/240	6
4.0 BFA-3CR/25206C	120/240	7
4.0 BFA-3CR/26651C	120/240	8
4.0 BFA-3CR/26805C	120/240	9
4.0 BFA-5DR/27696C	120/240	10
4.0 BFA-5DR/27919C	120/240	11
4.0 BFA-3CR/28530C	120/240	12

606-0205
606-0220

611-1142-09

Cylinder Block




Cylinder Block

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	110-3148	1	Block, Cylinder (Includes Parts Marked*)	22	110-2274	1	Cover, Valve (With Breather Port)
2	800-0051	5	*Screw, Cap - Hex Head (3/8-16x1-1/4")	23	123-1174	1	Spring, Breather Valve
3	850-0050	5	*Washer, Lock - Spring (3/8")	24	526-0018	1	Washer, Flat (1/4" Screw)
4	509-0041	1	*Seal, Oil	25	123-1175	1	Reed, Breather Valve
5	516-0072	4	*Pin, Drive - Bearing Stop	26	123-1173	1	Baffle, Breather Valve
6	104-0776	AR	*Shim (.005")	27	110-1879	1	Cover, Valve (Without Breather Port)
7			Bearing, Crankshaft - Rear (Includes Thrust Washer)	28	110-1921	3	Gasket, Valve Cover
	101-0450	1	* Standard	29	526-0122	18	Washer, Flat (5/16" Screw)
	101-0450-02	1	.002" Undersize	30			Head, Cylinder
	101-0450-10	1	.010" Undersize		110-2562	1	Right Side
	101-0450-20	1	.020" Undersize		110-2561	1	Left Side
	101-0450-30	1	.030" Undersize	31			Gasket, Head
8	104-0575	2	*Washer, Thrust		110-2287	2	All Except Key 3
9	101-0415	1	*Gasket, Bearing Plate		110-0892	2	Key 3
10	101-0439	1	*Plate, Bearing - Rear	32			Screw, Cap - Hex Head
11	517-0048	1	*Plug, Expansion - Welch		800-0540	12	5/16-18x1-5/8"(Grade 8)
12	110-0068	2	*Gasket, Intake Valve Guide		800-0541	6	5/16-18x2"(Grade 8)
13			*Guide, Valve	33			Tappet, Valve
	110-1807	2	Exhaust		115-0006	4	Standard
	110-3055	2	Intake - Sets With Valve Stem Oil Seals		115-0006-02	4	.002" Oversize
					115-0006-05	4	.005" Oversize
	110-3159	2	Intake - Sets Without Valve Stem Oil Seals	34	110-0639	8	Lock, Valve Spring
14	101-0405	2	*Bearing, Camshaft	35			Retainer, Valve Spring
15			Bearing, Crankshaft - Front		110-0904	4	Rotator - Keys 1,2,4,5,6,8, 9,10,12
	101-0432	1	* Standard		110-0893	4	Washer (Used In Place Of Rotators On Intake Valves)
	101-0432-02	1	.002" Undersize				Keys 7,11
	101-0432-10	1	.010" Undersize		110-0904	2	Rotator - Key 3
	101-0432-20	1	.020" Undersize		110-0893	2	Washer (Used In Place Of Rotators On Intake Valves)
	101-0432-30	1	.030" Undersize				Key 3
16	120-0735	1	*Tube, Oil Crankcase	36	110-0539	4	Spring, Valve
17			Insert, Valve Seat - Exhaust	37			Valve, Intake
	110-1824	2	* Standard		110-1808	2	Keys 1,2,3,4,7,8,9,11,12
	110-1824-02	2	.002" Oversize		110-2368	2	Keys 5,6,10
	110-1824-05	2	.005" Oversize	38			Valve, Exhaust
	110-1824-10	2	.010" Oversize		110-1955	2	All Except Key 3
	110-1824-25	2	.025" Oversize		110-1809	2	Key 3
18			Insert, Valve Seat - Intake	39	517-0120	1	Plug, Cylinder Block Opening
	110-0197	2	* Standard				Keys 1,2,8,9,12
	110-0197-02	2	.002" Oversize	40	110-3236	2	Seal, Valve - Intake (Optional)
	110-0197-05	2	.005" Oversize	41	517-0067	1	*Plug, Welch
	110-0197-10	2	.010" Oversize	42			Kits
	110-0197-25	2	.025" Oversize		168-0144	1	Gasket (Carbon Removal)
19	516-0141	2	*Pin, Gearcase Alignment		168-0143	1	Gasket (Complete Engine)
20	800-0010	2	Screw, Cap - Hex Head (1/4-20x1-3/4")	43	509-0168	2	Seal, Valve - Intake (Optional)
21	526-0063	2	Washer, Flat - Copper (1/4" Screw)				

* - Parts Included In 110-3148 Cylinder Block.


Camshaft



C 1056


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	150-0078	1	Ring, Retaining	6	105-0541	1	Washer, Thrust
2	150-1519	1	Hub, Governor Cup	7	150-0075	1	Pin, Center
3	150-1520	1	Cup, Governor	8	515-0001	1	Key, Woodruff
4	S10-0015	10	Ball, Governor	9	105-0637	1	Camshaft(Includes Center Pin)
5	105-0332	1	Gear, Camshaft (Includes Spacer And Plate)				

Crankshaft And Flywheel




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	104-0170	1	Screw, Cap - Hex Head Heat Treated (Special)	6	104-0043	1	Washer, Gear
2	850-0055	1	Washer, Lock - Spring (7/16")	7	104-0032	1	Gear, Crankshaft
3	526-0017	1	Washer, Flat (7/16" Screw)	8	515-0227	1	Kit, Key - All Except Keys 1,2
4	134-3871	1	Flywheel	9	515-0001	1	Key, Woodruff - All Keys
5	518-0014	1	Ring, Retaining	10	104-1331	1	Crankshaft (Includes Keys)

Piston And Rod



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Piston (Includes Pin And Retaining Rings)	5			Rod, Connecting (Includes Bolt And Nut)
	112-0186	2	Standard		114-0300	2	Standard
	112-0186-05	2	.005" Oversize		114-0300-10	2	.010" Undersize
	112-0186-10	2	.010" Oversize		114-0300-20	2	.020" Undersize
	112-0186-20	2	.020" Oversize		114-0300-30	2	.030" Undersize
	112-0186-30	2	.030" Oversize	6	114-0240	4	Bolt, Connecting Rod (Special)
	112-0186-40	2	.040" Oversize	7	870-0302	4	Nut, Hex - Crown Lock (5/16-24)
2	112-0229	2	Pin, Piston				
3	518-0311	4	Ring, Retaining				
4			Ring Set, Piston				
	113-0189	2	Standard				
	113-0189-05	2	.005" Oversize				
	113-0189-10	2	.010" Oversize				
	113-0189-20	2	.020" Oversize				
	113-0189-30	2	.030" Oversize				
	113-0189-40	2	.040" Oversize				


Gearcase



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	103-0667	1	Gearcase (Kit) (Includes Parts Marked*)	8	815-0046	2	*Screw, Machine - Pan Head (8-32x3/8")
2	150-1542	1	*Arm And Shaft, Governor	9	509-0040	1	*Seal, Oil - Crankshaft
3	509-0008	1	*Seal, Oil - Governor Shaft	10	103-0408	1	Gasket, Gearcase Mounting
4	510-0013	2	*Bearing, Needle	11	526-0065	5	Washer, Flat - Copper (5/16" Screw)
5	510-0014	1	*Ball, Bearing	12			Screw, Cap. Hex Head
6	516-0130	1	*Pin, Dowel - Governor Cup Stop		800-0032	4	5/16-18x1-3/4"
7	150-1187	1	*Yoke, Governor		800-0034	1	5/16-18x2-1/4"
				13	150-0678	1	*Clip, Sensitivity Adjustment

* - Parts Included In 103-0667 Gearcase.


Governor



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	870-0131	1	Nut, Hex - Self Locking (1/4-20")	8	870-0131	1	*Nut, Hex - Self Locking (1/4-20)
2	150-0096	1	Stud, Speed Adjustment	9	150-0629	1	*Rod, Governor Arm To Carburetor
3	150-1612	1	Spring, Governor	10	870-0053	1	*Nut, Hex (#10-32)
4	800-0004	2	Screw, Cap - Hex Head (1/4-20x5/8")	11	150-0639	1	*Joint, Ball
5	526-0063	2	Washer, Flat (1/4" Screw)	12	149-0003	1	Gasket, Governor Bracket
6	150-1577	1	Bracket, Governor		150-0630	1	Linkage, Governor (Includes Parts Marked*)
7	518-0004	1	Clip, Retaining				


* - Parts Included In 150-0630 Governor Linkage.

Oil System



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	122-0320	1	Adapter, Oil Filter	11	336-3377	1	Lead, Electrical - Low Oil Pressure Switch
2	122-0321	1	Gasket, Oil Filter Adapter Mounting	12	526-0066	1	Washer, Flat (3/8" Screw)
3	122-0645	1	Filter, Oil - Spin-On	13	801-0050	1	Screw, Cap - Hex Head (3/8-24x1")
4	122-0347	1	Seal, Air - Oil Filter	14	120-0140	1	Spring, Oil By-Pass Valve
5	122-0360	1	Drain, Oil Filter	15	120-0398	1	Valve, Oil By-Pass
6	502-0053	1	Elbow, Street - 45°	16	850-0040	2	Washer, Lock - Spring (1/4")
7	309-0319	1	Switch, Low Oil Pressure	17	800-0007	2	Screw, Cap - Hex Head (1/4-20x1")
8	800-0028	2	Screw, Cap - Hex Head (5/16-18x1")	18	120-0491	1	Pump, Oil (Components Not Sold Separately)
9	526-0065	2	Washer, Flat - Copper (5/16" Screw)	19	120-0161	1	Kit, Gasket - Oil Pump
10	815-0194	2	Screw, Tapping - Hex Head (#10-32x3/8")	20	120-0413	1	Cup, Oil Pump Intake (Includes Screw Pipe And Cup)

Oil Base And Mounting Hardware




LS 1003-1

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	102-0957	1	Base, Oil (Includes Parts Marked*)	22			#Washer, Lock (7/16")
2	102-1200	1	Gasket, Oil Base	850-0055	2	2	Engine End
3	526-0030	4	Washer, Flat (3/8" Screw)	850-0055	1	1	Generator End(Left Side)
4	123-1400	1	Cap And Indicator, Oil Fill	850-0055	1	1	Generator End(Right Side)
5	123-0191	1	Gasket, Oil Fill Cap	23			#Washer, Flat (7/16" Screw)
6	504-0092	1	Valve, Oil Drain	526-0014	2	2	Engine End
7			Washer, Flat (7/16" Screw)	526-0014	1	1	Generator End(Left Side)
	526-0195	2	Engine End	526-0014	1	1	Generator End(Right Side)
	526-0195	2	Generator End	24			#Washer, Flat (9/16" Screw)
8	102-1275	1	*Gasket, Oil Pan Mounting	526-0198	2	2	Engine End
9	102-0889	1	*Pan, Oil Base	526-0198	2	2	Generator End(Left Side)
10	821-0018	20	*Screw, Cap - Hex Washer Head (1/4-20x5/8")	526-0198	1	1	Generator End(Right Side)
11			Screw, Hex Head - Cap (7/16-14x3-3/4")	25			#Washer, Flat (1" Screw)
	800-0082	2	Engine End	526-0286	1	1	Generator End(Left Side)
	800-0082	2	Generator End	526-0286	1	1	Generator End(Right Side)
12	800-0047	1	Screw, Cap - Hex Head (3/8-16x5/8")	26			#Washer, Flat (5/8" Screw)
13	856-0010	1	Washer, Lock -EIT (3/8")	526-0038	2	2	Engine End
14			Package, Hardware Mounting (Includes Parts Marked#)	526-0038	1	1	Generator End
	402-0477	1	Engine End	27	800-0064	4	Screw, Cap - Hex Head (3/8-16x4-1/2")
	402-0480	2	Generator End	28	850-0050	4	Washer, Lock - Spring (3/8")
15	402-0283	2	#Cushion, Vibration	29			Strap, Ground
16			#Cushion, Vibration - Generator End	337-0418	1	1	5" Long - Key 6
	402-0283	1	Left Side	337-2055	1	1	6" Long - All Except Key 6
	402-0283	1	Right Side	30	816-0197	1	Bolt, Carriage (7/16-14 x 1-1/4") - All Except Key 6
17			#Spacer, Sleeve	31	856-0016	1	Washer, Lock (EIT) (5/8")
	402-0290	2	Engine End	32	403-1484	1	Plate, Mounting - All Except Key 6
	402-0290	1	Generator End(Left Side)	33	856-0012	1	Washer, Lock (EIT) (7/16")
	402-0290	1	Generator End(Right Side)	34	862-0004	1	Nut, Hex (7/16-14)
18			#Snubber	35			#Bolt, Carriage (7/16-14x3-1/2")
	402-0282	2	Engine End	816-0206	2	2	Engine End
	402-0282	1	Generator End(Left Side)	816-0206	1	1	Generator End(Left Side)
	402-0282	1	Generator End(Right Side)	816-0206	1	1	Generator End(Right Side)
21			#Nut, Hex (7/16-14)	36	332-0142	1	Terminal, Ground
	862-0004	2	Engine End	37	856-0006	1	Washer, Lock - EIT (1/4")
	862-0004	1	Generator End(Left Side)	38	850-0055	1	Washer, Lock (7/16")
	862-0004	1	Generator End(Right Side)				

* - Parts Included In 102-0956 Oil Base.

- Parts Included In Hardware Mounting Package.


Air Housing



CS 1065

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	821-0008	4	Screw, Cap - Hex Head (1/4-20x5/16")	6	134-3701	1	Housing, Cylinder Air - Left Side
2	134-4387	1	Scroll 2 Position, With-Out Guard - Key 9	7	134-3700	1	Housing, Cylinder Air - Right Side
	134-3149	1	Includes Guard - Keys 1,2,3	8	134-3418	1	Guard, Scroll Screen
3	821-0010	2	Screw, Cap - Hex Washer Head (1/4-20x1/2" Long)		134-4316	1	Keys 1, 2, 3 Guard - Wire Type - All Except Key 3
4	134-3888	1	Backplate, Scroll 3 O-Clock Position - Key 4	9	815-0421	4	Screw, Self-Tapping - Hex Head (10-16x1/2")
	134-3688	1	6 O-Clock Position - Keys 2, 3,5,6,7,10,11	10	850-0040	4	Washer, Lock (1/4")
	134-3928	1	9 O-Clock Position - Keys 8,9	11	309-0077	1	Switch, Temperature (Open 180° - Close 220° F)
5	815-0261	5	Screw, Tapping - Hex Head (1/4-20x1/2")				


Fuel System (Low Profile Air Cleaner)
Keys 1,2,3,4,5,7,8,9,10,11,12



Fuel System (Low Profile Air Cleaner)
Keys 1,2,3,4,5,7,8,9,10,11,12

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	123-1417	1	Filter, Breather Hose - Gasoline Fuel System	32	815-0285	2	Screw, Machine - Round Head W/ET (#8-32x5/16")
2	503-0280	1	Clamp, Hose - Gasoline Fuel System	33	526-0062	2	Washer, Flat - Brass (#10 Screw)
3			Breather	34	815-0110	1	Screw, Machine - Fillister Head (#10-32x7/8")
	123-1277	1	Tube (Gasoline Fuel System)	35	850-0030	1	Washer, Lock - Spring (#10)
	503-0103	1	Hose (LP Fuel System) - Keys 7,11	36	332-0556	1	Connector, Fuel Pump Lead Screw,
4	503-0769	1	Clamp, Hose - Gasoline Fuel System	37	804-0017	3	Socket Head - Gasoline Fuel (#10-32x1/2" Long)
5			Adapter, Air Duct		813-0111	3	Round Head, Machine - LP Fuel System (#10-32x2-1/4")
	140-1492	1	Gasoline Fuel System				Adapter, Choke
	140-1719	1	LP Fuel System - Keys 7,11	38	153-0499	1	Screw, Self-Tapping - Hex Head (#10-32x7/8" Long)
6			Carburetor, Complete (Includes Mounting Gasket) (See Separate Page For Components)	39	815-0359	2	Seal, O-Ring
	146-0419	1	Gasoline Fuel System - Nikki	40	509-0145	1	Gasoline Fuel System
	146-0404	1	LP Fuel System - Keys 7,11		509-0145	2	LP Fuel System - Keys 7,11
7	154-0733	1	Gasket, Carburetor To Adapter	41	140-1520	1	Clamp, Air Duct
8	154-1977	1	Adapter, Carburetor	42	140-1502	1	Seal, Air Duct To Adapter
9	145-0438	1	Gasket, Adapter To Manifold	43	518-0390	2	Screw, Wing (1/4-20x3/4")
10	800-0028	2	Screw, Cap - Hex Head (5/16-18x1")	44	526-0021	1	Washer, Flat (1/4" Screw)
11	850-0045	2	Washer, Lock - Spring (5/16")	45	140-1503	1	Duct, Air Cleaner
12	800-0023	2	Screw, Cap - Hex Head (1/4-20x1-3/8")	46	140-1531	1	Bracket, Air Duct Support
13	850-0040	2	Washer, Lock - Spring (1/4")	47	821-0009	3	Screw, Cap - Hex Head Locking (1/4-20x3/8")
14			Manifold, Intake	48	140-1521	1	Seal, Air Duct To Breather Port
	154-2206	1	LP Fuel System - Keys 7,11	49	870-0212	2	Nut, Hex - Locking (1/4-20)
	154-2666	1	Gasoline Fuel System - Keys 1,2,3,4,5,8,12	50	865-0019	1	Nut, Wing (1/4-20)
15	154-1446	2	Gasket, Intake Manifold	51	526-0158	2	Washer, Flat (1/4" Screw)
16	800-0033	4	Screw, Cap - Hex Head (5/16-18x2")	52	870-0212	1	Nut, Hex - Locking (1/4-20)
17	850-0045	4	Washer, Lock - Spring (5/16")	53	816-0070	1	Bolt, Carriage (1/4-20x6-1/2")
18	502-0003	1	Connector, Inverted Male	54	140-0495	1	Element, Air Cleaner
19	149-1531	1	Line, Fuel - Gasoline	55	140-1504	1	Cover, Air Cleaner
20	518-0350	1	Clamp, Loop - Insulated Keys 1,2,3,4,5,8,9,10,12	56	140-1522	1	Spacer, Air Intake
21	862-0015	1	Nut, Hex (5/16-18)	57	140-1529	1	Bracket, Air Intake Duct
22	502-0002	1	Elbow, Inverted Male	58	140-1528	1	Brace, Air Intake Duct
23	502-0313	1	Connector, Hose (90°)	59	140-1533	2	Seal
24	149-1828	1	Pump, Fuel (Electric)	60	140-1672	1	Wrapper, Air Cleaner - Keys 5,10,11
26	332-0529	1	Terminal, Fuel Pump Lead	61	123-1484	1	Tube, Breather (Copper) - LP Fuel System - Keys 7,11
27	821-0008	2	Screw, Hex - Lock (1/4-20x5/16")	62	148-0840	1	Adapter, Carburetor - LP Fuel System - Keys 7,11
28	153-0440	1	Housing, Choke (Includes Screw)	63	502-0575	1	Elbow, Hose - 45° (1/2 NPT)
29	153-0017	1	Bi-Metal, Choke				LP Fuel System - Keys 7,11
30	153-0114	1	Element And Cover, Choke	64	850-0030	3	Washer, Lock (#10)
31	332-0527	1	Terminal, Tab				LP Fuel System

Fuel System (High Profile Air Cleaner) Key 6




XFS 1462

Fuel System (High Profile Air Cleaner) **Key 6**

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	154-2206	1	Manifold, Intake	24	526-0062	2	Washer, Flat - Brass (Special)
2	145-0438	1	Gasket, Manifold To Carburetor Adapter	25	153-0114	1	Element And Cover, Choke
3	146-0440	1	Carburetor, Gasoline (See Separate Page For Components)	26	153-0017	1	Bi-Metal, Choke
4	502-0003	1	Connector, Inverted Male	27	153-0058	1	Housing, Choke
5	140-1228	1	Element, Air Cleaner	28	821-0004	2	Screw, Cap - Hex Washer Head (#10-32x5/16")
6	140-1711	1	Housing, Air Cleaner	29	153-0541	1	Link, Choke
7	140-1496	1	Wrapper, Filter Element	30	332-0527	1	Terminal, Tab
8	140-1494	1	Cover, Air Cleaner	31	123-1417	1	Filter, Breather Tube
9	153-0539	1	Bracket And Bushing, Choke	32	123-1429	1	Tube, Breather
10	509-0145	1	Seal, O-Ring	33	140-1736	1	Bracket, Air Cleaner Support
11	146-0241	1	Shaft, Electric Choke	34	821-0009	1	Screw, Cap - Hex Washer Head (1/4-20x3/8")
12	518-0387	1	Ring, Retainer	35	815-0110	1	Screw, Machine - Fillister Head (#10-32x7/8")
13	850-0040	2	Washer, Lock - Spring (1/4")	36	850-0030	1	Washer, Lock - Spring (#10)
14	800-0023	2	Screw, Cap - Hex Head (1/4-20x1-3/8")	37	800-0033	3	Screw, Cap - Hex Head (5/16-18x2")
15	154-1977	1	Adapter, Carburetor	38	850-0045	4	Washer, Lock - Spring (5/16")
16	865-0006	1	Nut, Wing (1/4-20)	39	154-1446	2	Gasket, Intake Manifold
17	800-0028	2	Screw, Cap - Hex Head (5/16-18x1")	40	862-0015	1	Nut, Hex (5/16-18)
18	850-0045	2	Washer, Lock - Spring (5/16")	41	518-0350	1	Clamp, Loop - Insulated
19	154-0733	1	Gasket, Carburetor To Adapter	42	149-1705	1	Line, Fuel
20	145-0521	1	Deflector, Carburetor Air Intake	43	149-1828	1	Pump, Fuel - Electric
21	815-0470	3	Screw, Machine - Hex Head (#10-32x1-1/2")	44	502-0313	1	Connector, Hose (90°)
22	526-0234	3	Washer, Flat (#10 Screw)	45	502-0002	1	Elbow, Inverted Male
23	815-0285	2	Screw, Machine - Round Head W/ET (#8-32x5/16")	46	821-0008	2	Screw, Cap - Hex Lock (1/4-20x5/16")
				47	332-0529	1	Terminal, Fuel Pump Lead
				48	332-0556	1	Connector, Fuel Pump Lead
				49	503-0280	1	Clamp, Breather Tube
				50	800-0034	1	Screw, Cap - Hex Head (5/16-18x2-1/4")


Carburetor Components LPG



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	146-0404	1	Carburetor, LPG (Includes Mounting Gasket)	12		1	Body (Not Sold Separately)
1	815-0389	1	Screw, Hex Washer Head	13	154-0733	2	*Gasket, Mounting - Carburetor
2	146-0418	1	Shaft, Throttle (Kit)	14	146-0327	1	Variable Jet Kit - Optional (High Altitude Application) (Includes Parts Marked +)
3	146-0322	1	*Screw and Plug Kit	15	146-0343	1	+Jet, Power - Variable (Includes Gasket)
4	146-0326	1	*Gasket Kit	16	146-0340	1	+Retainer, Needle - Power (Includes Gasket)
5	509-0145	1	Seal, O-Ring	17	146-0341	1	+Spring, Needle - Power
6	146-0329	1	*Valve and Seat Kit	18	146-0342	1	+Needle, Power - Complete
8	146-0420	1	Jet, Idle	20	146-0356	1	Kit, Repair (Includes Parts Marked *)
9	146-0335	1	*Needle, Adjusting - Idle				
10	146-0331	1	*Spring, Needle - Idle Adjusting				
11		1	Intake, Air (Not Sold Separately)				

* - Parts Included in 146-0356 Repair Kit.
+ - Parts Included in 146-0327 Variable Jet Kit.

Carburetor Components Gasoline - Nikki




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	146-0419	1	Carburetor, Complete (Includes Mounting Gasket)	12		1	Body (Not Sold Separately)
	146-0440	1	Low Profile Models	13	154-0733	2	*Gasket, Mounting - Carburetor
	146-0417	1	High Profile Models	14	146-0327	1	Variable Jet Kit - Optional (High Altitude Application)
1	146-0418	1	Choke, Shaft Kit				(Includes Parts Marked +)
2	146-0418	1	Shaft, Throttle (Kit)	15	146-0343	1	+Jet, Power - Variable (Includes Gasket)
3	146-0322	1	*Screw and Plug Kit	16	146-0340	1	+Retainer, Needle - Power (Includes Gasket)
4	146-0326	1	*Gasket Kit	17	146-0341	1	+Spring, Needle - Power
5	146-0325	1	Float, Kit	18	146-0342	1	+Needle, Power - Complete
6	146-0329	1	*Valve and Seat Kit	19	145-0438	1	*Gasket, Mounting - Carburetor
7	146-0343	1	Jet, Power	20	146-0356	1	Kit, Repair (Includes Parts Marked *)
8	146-0420	1	Jet, Idle				
9	146-0335	1	*Needle, Adjusting - Idle				
10	146-0331	1	*Spring, Needle - Idle Adjusting				
11		1	Intake, Air (Not Sold Separately)				

* - Parts Included in 146-0356 Repair Kit.

+ - Parts Included in 146-0327 Variable Jet Kit.

Ignition



ES 1116


REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	166-0772	1	Coil, Ignition
2	166-0588	1	Clamp, Coil
3	821-0009	4	Screw, Cap - Hex Washer Head (1/4-20x3/8")
4	167-1602	2	Cable, Spark Plug
7	160-0558	2	Nipple, Spark Plug Cable
8	160-1303	1	Box, Breaker (See Separate Page For Components) (Includes Mounting Gasket)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
9	160-1150	1	Gasket, Breaker Box Mounting
11	160-1151	1	Plunger, Breaker Points
12	167-0298	2	Plug, Spark
13	166-0554	2	Nut, Hex (Metric)
14	850-2005	2	Washer, Lock - Spring (Metric)
15	312-0051	1	Condenser, Ignition (.5 MFD)

160-1376 1 Kit, Electronic (converts Breaker Ignition to Electronic)

PSB#556/ur


Breaker Box



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	160-1303	1	Breaker Box (Includes Parts Marked*)	8	802-0034	2	*Screw, Cap - Socket Head (1/4-20 x 3/4")
1	802-0022	1	*Screw, Cap - Hex Socket (#10-24 x 1-1/2")	9	850-0040	2	Washer, Lock (1/4")
2	509-0065	1	*Retainer (O-Ring)	10	160-1183	1	*Point Set, Breaker
3	526-0008	1	*Washer, Flat (#10 Screw)	11	160-1219	1	*Base, Breaker
4	160-1285	1	*Cover, Breaker Box	12	160-1150	1	*Gasket, Breaker Box
5	815-0358	1	*Screw, Cap - Slotted (#8-32 x 3/16")	14	336-2378	1	Lead, Breaker Box to Coil
7	312-0246	1	*Condenser	15	160-1311	1	Tune Up Kit (Includes Points and Condenser)

* - Parts Included in 160-1303 Breaker Box.


Exhaust System
(Sets With High Profile Air Cleaner)
Key 6, 5 (Optional)



EXS 1083


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	154-1762	1	Manifold, Exhaust - LH Down	5	154-2310	1	Elbow, Exhaust (Right)
2	800-0026	4	Screw, Cap - Hex Head (5/16-18 x 3/4")	6	154-2311	1	Elbow, Exhaust (Left)
3	850-0045	4	Washer, Lock - Spring (5/16")	7	155-1256	2	Clamp, Muffler
4	154-1725	2	Gasket, Exhaust Manifold	8	155-1851	1	Muffler, Exhaust (Spark Arrestor)

**Exhaust System
(Sets With Low Profile Air Cleaner)
UL Listed And CSA Certified
Keys 1,2,3,4,5,7,8,9,10,11,12**



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	154-1947	1	Manifold, Exhaust 5.25" Tall - Prior To 6/83 Keys 1,2,3,9,10,11	11	155-1234	1	Bracket And Clamp, Muffler
	154-2140	1	5.75" Tall - Keys 4,8	12	155-1258	1	Muffler, Exhaust
	154-2425	1	Includes Heat Shield - Begin 6/83		155-1520	1	End Inlet - Spark Arrestor
	154-1762	1	Left Hand Down - Key 10,5		155-1520	1	Center Inlet - Key 9
2	800-0026	4	Screw, Cap - Hex Head (5/16-18x3/4")		155-1851	1	Spark Arrestor - Key 7
3	850-0045	4	Washer, Lock - Spring (5/16")		155-1910	1	Center Inlet (Used With 90° Bend Exhaust Tube)
4	154-1725	2	Gasket, Exhaust Manifold	13	154-2146	1	Shield, Heat - Down Pipe (14" Long) - Delete Keys 7,8
5	154-2061	1	Gasket, Exhaust Tube	14	821-0010	4	Screw, Cap - Hex Head - Locking (1/4-20x1/2")
6	154-1578	1	Tube, Exhaust 17" Long	15	154-1972	1	Shield, Heat - Exhaust Manifold - Prior To 6/83 - Delete Keys 7,8
	154-2143	1	12-1/2" Long	16	503-0107	1	Clamp, Shield To Exhaust Tube
	154-2554	1	90° Bend - With Attached Clamp (18" Long) (X 13.5")	17	154-1883	1	Bracket, Heat Shield - Left Side - Keys 9,12
7	800-0030	2	Screw, Cap - Hex Head (5/16-18x1-1/4")	18	154-1886	1	Bracket, Heat Shield - Right Side - Keys 9,12
8	850-0045	2	Washer, Lock - Spring (5/16")	19	821-0010	1	Screw, Cap - Locking Head (1/4-20x1/2")
9	862-0015	2	Nut, Hex (5/16-18)	20	152-0184	1	Spacer, Heat Shield Mounting - Key 9
10	155-1239	1	Clamp, Muffler				

Generator
Keys 1,5,8,9,12



**Generator
Keys 1,5,8,9,12**

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	862-0015	4	Nut, Hex (5/16-18)	21	232-0596	1	Clip, Bearing Retainer
2	231-0164	1	Adapter, Generator To Engine (Includes Alignment Pins)	22			Block, Generator Brush (Includes Parts Marked+)
3	850-0050	4	Washer, Lock - Spring (3/8")		212-0361	1	Top
4	800-0050	4	Screw, Cap - Hex Head (3/8-16x1-1/4")		212-0345	1	Right Side
5	520-0732	1	Stud, Armature Through		212-0352	1	Bottom
6			Armature (Includes Parts Marked*)		212-0353	1	Left Side
	201-2421	1	120/240 Volt, 3 Phase - Key 5	23	815-0341	4	+Screw, Cap - Hex Head Brass (#10-32x1")
	201-2504	1	120/240 Volt, 1 Phase - Keys 9,12	24	853-0008	4	+Washer, Lock - ET (#10)
	201-2405	1	120/240 Volt, 1 Phase - Keys 1,8	25	871-0010	8	+Nut, Hex - Brass (#10-32)
7	204-0110	1	*Ring, Collector	26	853-0008	4	+Washer, Lock - ET (#10)
8	203-0153	1	*Commutator	27	526-0049	8	+Washer, Flat - Brass (#10 Screw)
9	510-0047	1	*Bearing, Ball	28	871-0010	8	+Nut, Hex - Brass (#10-32)
10			Stator, Wound	29	214-0095	4	+Brush, Commutator (DC)
	220-1818	1	120/240 Volt, 1 Phase - Keys 9,12	30	214-0096	8	+Brush, Collector Ring (AC)
	220-1820	1	120/240 Volt - Keys 1,5,8	31	212-1232	12	+Spring, Brush
11	516-0196	4	Pin, Alignment	32	815-0359	17	Screw, Cap - Hex Head - Locking - (#10-32x7/8")
12	860-0011	1	Nut, Hex (#10-24)	33	402-0475	2	Support, Generator
13	304-0015	2	Washer, Centering - Resistor	36	205-0090	1	Fan, Cooling
14			Resistor, Fixed	37	850-0055	1	Washer, Lock - Spring (7/16")
	353-0072	1	5.7 Ohms At 25 Watts, 2.5 Ohms At 50 Watts (4-1/2" Long) - Key 3	38	870-0203	1	Nut, Hex (7/16-20)
	353-0084	1	5.7 Ohms At 25 Watts, 1.6 Ohms At 50 Watts (4-1/2" Long) - Keys 7,12	39	232-2107	1	Cover, Generator
15	850-0030	1	Washer, Lock - Spring (#10)	40	850-0040	2	Washer, Lock - Spring (1/4")
16	812-0118	1	Screw, Machine - Round Head (#10-24x5")	41	812-0156	4	Screw, Round Head - Machine (1/4-20x1/2")
17	800-0043	4	Screw, Cap - Hex Head (5/16-18x5")	42	234-0362	1	Wrapper, Generator
18	850-0045	4	Washer, Lock - Spring (5/16")	43			Harness, Wiring
19	526-0115	4	Washer, Flat (5/16" Screw)		338-0946	1	1 Phase - Keys 1,8
20	211-0364	1	Bell, End (Includes 4 Locating Pins)		338-1419	1	3 Phase (6 Wire) - Key 5
					338-1852	1	1 Phase (4 Wire) - Keys 9,12
				45			+Block, Generator Brush
					212-0360	2	Top And Left Side
					212-0359	2	Bottom And Right Side
				46	304-0706	2	Bracket, Resistor Mounting

* - Parts Included In The Armature.

+ - Parts Included In The Brush Block.

870-0269




Generator- Extended Shaft Keys 2,3,4,6,7,10,11

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	862-0015	4	Nut, Hex (5/16-18)	22			Block, Generator Brush (Includes Parts Marked*)
2	231-0164	1	Adapter, Generator To Engine (Includes Alignment Pins)		212-0361	1	Top
3	850-0050	4	Washer, Lock - Spring (3/8")		212-0345	1	Right Side
4	800-0050	4	Screw, Cap - Hex Head (3/8-16x1-1/4")		212-0352	1	Bottom
5			Stud, Armature Through		212-0353	1	Left Side
	520-0733	1	7/16 x 17-1/8" Long - Key 6	23	815-0341	4	+Screw, Cap - Hex Head Brass (#10-32x1")
	520-0781	1	7/16 x 17-7/8" Long - Keys 2,3,4,7,10,11	24	853-0008	8	+Washer, Lock - ET (#10)
6			Armature (Includes Parts Marked*)	25	871-0010	8	+Nut, Hex - Brass (#10-32)
	201-2524	1	120/240 Volt, 1 Phase Keys 4,7	26	853-0008	8	+Washer, Lock - ET (#10)
	201-2531	1	120/240 Volt, 3 Phase - Keys 10,11	27	526-0049	8	+Washer, Flat - Brass (#10)
	201-2528	1	120/240 Volt, 3 Phase - Key 6	29	214-0095	4	+Brush, Commutator (DC)
	201-2573	1	120 Volts, 1 Phase - 2 Step Battery Charger - Keys 2,3	30	214-0096	8	+Brush, Collector Ring (AC)
7			*Ring, Collector	31	212-1232	12	+Spring, Brush
	204-0110	1	4 Wire, 120/240 Volt	32	815-0359	17	Screw, Cap - Hex Head - Locking - (#10-32x7/8")
	204-0125	1	2 Step Battery Charger - 120 Volt Single Phase	33	402-0475	2	Support, Generator
8	203-0153	1	*Commutator	36	205-0116	1	Fan, Cooling
9	510-0047	1	*Bearing, Ball	37	850-0055	1	Washer, Lock - Spring (7/16")
10			Stator, Wound	38	870-0203	1	Nut, Hex (7/16-20)
	220-1820	1	120/240 Volt - Keys 4,6,7, 10,11	39	232-2827	1	Cover, Generator (Includes Parts Marked#)
	220-1823	1	2 Step Battery Charger - 120 Volt - Keys 2,3	40	850-0040	4	Washer, Lock - Spring (1/4")
11			Pin, Alignment	41	812-0156	4	Screw, Round Head - Machine (1/4-20x 1-1/2")
	516-0196	4	Keys 2,7,10	42	234-0362	1	Wrapper, Generator
	516-0182	4	Keys 3,4,6,11	43			Harness, Wiring
12	515-0015	1	Key, Extended Shaft (3/16x1-3/4")		338-0947	1	3 Phase - Keys 10,11
14			Resistor, Fixed		338-0946	1	1 Phase - Keys 4,7
	353-0072	1	5.7 Ohms At 25 Watts, 2.5 Ohms At 50 Watts (4-1/2" Long) - Keys 5,6		338-1419	1	3 Phase (6 Wire) - Key 6
	353-0084	1	5.7 Ohms At 25 Watts, 1.6 Ohms At 50 Watts (4-1/2" Long) - Keys 7,10,11		338-0948	1	1 Phase - 2 Wire - Keys 2,3
15	526-0044	2	Washer, Flat (1" Screw)	44	850-0030	4	Washer, Lock (#10)
16	232-2586	1	Hub, Fan	45			+Block, Generator Brush
17	800-0043	4	Screw, Cap - Hex Head (5/16-18x5")		212-0360	2	Top And Right Side
18	850-0045	4	Washer, Lock - Spring (5/16")		212-0359	2	Bottom And Left Side
19	526-0115	4	Washer, Flat (5/16" Screw)	46	526-0032	1	Washer, Flat (7/16" Screw)
20	211-0365	1	Bell, End (Includes 4 Alignment Pins)	47	804-0016	4	Screw, Socket Head (10-32x3/8")
21	232-0596	1	Clip, Bearing Retainer	48	304-0015	2	Washer, Centering - Resistor
				49	304-0706	2	Bracket, Resistor Mounting
				50	812-0118	1	Screw, Pan Head (#10 x 5")
				51	850-0030	1	Washer, Lock (#10)
				52	860-0011	1	Nut, Hex (#10-24)
				53	815-0333	2	Screw, Round Head (#10-32x1/2")
				54	232-2587	1	#Cover, Fan
				55	234-0530	1	#Screen, Fan
				56	815-0350	4	#Screw, Hex Washer Head - Slotted (#10-32x3/8")
				57	526-0009	4	#Washer, Flat (#10 Screw)
					98-5713	1	Label, Warning (Not Shown)

* - Parts Included In The Armature.
+ - Parts Included In The Brush Block.
- Parts Included In 232-2827 Fan Cover.

Control



Control
Keys 1,2,3,4,7,8,9,10,11,12

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	301-4634	1	Box, Control	27			Washer, Lock
2			Panel, Control	853-0003	2		External (#6)
	301-4442	1	Units Without Ignition Switch	854-0006	2		Internal (#6)
	301-9011	1	Units With Ignition Switch	28	860-0005	2	Nut, Hex (#6-32)
3			Cover, Control Box (Includes Schematic)	29	323-0488	5	*Pin, Connector - Female
	301-4545	1	2 Step Battery Charger Without Ignition Switch Keys 1,9,10,11,12	30			Harness, Wiring (Includes Parts Marked*)
	301-4894	1	2 Step Battery Charger Without Ignition Switch Keys 2,3,4,7,8	338-1200	1		Without Key Operated Ignition Switch - With Electric Choke Keys 1,2,3,4,8,9,10,12
4	301-4441	1	Plate, Control	338-1677	1		Without Key Operated Ignition Switch - Without Electric choke - Keys 7,11
5	332-0142	1	Terminal, Solderless - Keys 7,11	338-1820	1		With Key Operated Ignition Switch - With Electric Choke
6	821-0008	4	Screw, Hex - Self-Lock (1/4-20x5/16")	31	815-0350	1	Screw, Hex Washer Head (10-32x3/8")
7	518-0056	1	Screw, Wing (#10-32x1/2")	32	332-1043	1	*Jumper, Terminal Block
8	307-1617	1	Relay, Start Solenoid	33	357-0030	1	*Rectifier, Silicon
10	307-2562	2	*Relay, Ignition (Crank And Run)	34			Harness, Wiring - Remote
12	870-0131	4	Nut, Hex W/ET (#10-32)	338-1082	1		Includes Parts Marked+ - Key 9
13	308-0383	1	Switch, Start-Stop	338-1078	1		Includes Parts Marked#
14			Holder, Fuse	35	323-0400	1	+Pin, Housing Connector
	321-0175	2	Units Without Ignition Switch	36	323-0500	5	+Pin, Connector - Male
	321-0175	1	Units With Ignition Switch	37	508-0015	1	Washer, Insulator
15			Fuse	38	323-0440	1	*Housing, Socket
	321-0174	2	5 Ampere	38A			Strip, Marker
	321-0146	1	10 Ampere	332-2099	1		Use With 332-0254 Block - Without Ignition Switch - Keys 9,12
16	508-0208	1	Bushing, Nylon	332-2103	1		Use With 332-0699 Block
17	331-0088	1	Bushing, Insulating	332-2313	1		Use With 332-0254 Block - With Ignition Switch
18	508-0191	1	Bushing, Nylon	39	320-0540	2	Breaker, Circuit - 15 Amp - Keys 9,12
19	304-0580	1	Insulator, Resistor Mounting	41	508-0021	1	Grommet, Rubber
20	352-0161	1	*Resistor, 100-Ohm, 5 Watt	42	332-0942	16	*Tie, Cable
21	812-0087	1	Screw, Machine - Round Head (#8-32x1-1/2")	43	305-0383	1	Regulator, Voltage
22	870-0221	1	Nut, Hex W/ET (#8-32)	44	308-0788	1	Switch, Ignition - With Key
23	821-0004	5	Screw, Cap - Hex Head (#10-32x5/16")	45	307-1575	1	Relay, Ignition (Key 308-0921)
24	854-0010	2	Washer, Lock - IT (#10)	46	332-0556	1	Connector, Relay
25			Block, Terminal				Connector, Wire Nut (Not Shown)
	332-0254	1	4 Terminal, 50 Amps - Keys 9,12	323-1088	3		Keys 4,7,8,9,12
	332-0699	1	* 6 Terminal, 20 Amps	323-1088	2		Keys 2,3
26			Screw, Round Head - Machine (#6-32x5/8")				
	812-0065	2	(#6-32x3/4") - Units With Ignition Switch - Key Operated				
	812-0066	2					


* - Parts Included In Wiring Harness 338-1200, 338-1677, 338-1820.

- Parts Included In Wiring Harness 338-1078.

+ - Parts Included In Wiring Harness 338-1082.

Handwritten:
Q/W for Key (308-0921)
see NH JF/pty

Control
Keys 5,6



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	234-0664	1	Bracket, Generator Frame
2	307-1193	1	Relay, Start Solenoid

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
3	821-0009	2	Screw, Cap - Hex Washer Head (1/4-20x3/8")

Labels, Paint And Thread Sealant

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
98-2899		1	Decal, Warning - Battery - Keys 1,2,3,4,5,7,8,9,10,11,12	98-4267		1	Decal, Identification (4.0 RV) Keys 4,8,10,11
98-3234		1	Decal, Control Panel - Keys 1, 2,3,4,7,8,9,10,11,12	98-4690		1	Decal, Identification (4.0 Gen. Set) - Keys 7,9,12
98-3278		1	Decal, Choke Label - Keys 1,4, 5,8,10,11	518-0452		1	Sealant, Thread (50cc. Bottle)
98-4856		1	Decal, Service Instructions - Keys 2,3,4,5,7,8,9,10,11,12	525-0305		1	Paint, Enamel Touch-Up - Green (Non-Metallic) 13oz. Pressur- ized Can
98-2863		1	Decal, Service Instructions - Keys 1,6				

Numerical Index

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
98-2863	31	110-1809	5	123-0191	12	146-0327	19
98-2899	31	110-1824	5	123-1173	5	146-0329	18
98-3234	31	110-1824-02	5	123-1174	5	146-0329	19
98-3278	31	110-1824-05	5	123-1175	5	146-0331	18
98-4267	31	110-1824-10	5	123-1277	15	146-0331	19
98-4690	31	110-1824-25	5	123-1400	12	146-0335	18
98-4856	31	110-1879	5	123-1417	15	146-0335	19
98-5713	27	110-1921	5	123-1417	17	146-0340	18
101-0405	5	110-1955	5	123-1429	17	146-0340	19
101-0415	5	110-2274	5	123-1484	15	146-0341	18
101-0432	5	110-2287	5	134-3149	13	146-0341	19
101-0432-02	5	110-2368	5	134-3418	13	146-0342	18
101-0432-10	5	110-2561	5	134-3688	13	146-0342	19
101-0432-20	5	110-2562	5	134-3700	13	146-0343	18
101-0432-30	5	110-3055	5	134-3701	13	146-0343	19
101-0439	5	110-3148	5	134-3871	7	146-0343	19
101-0450	5	110-3159	5	134-3888	13	146-0356	18
101-0450-02	5	110-3236	5	134-3928	13	146-0356	19
101-0450-10	5	112-0186	8	134-4316	13	146-0404	15
101-0450-20	5	112-0186-05	8	134-4387	13	146-0404	18
101-0450-30	5	112-0186-10	8	140-0495	15	146-0417	19
102-0889	12	112-0186-20	8	140-1228	17	146-0418	18
102-0957	12	112-0186-30	8	140-1492	15	146-0418	19
102-1200	12	112-0186-40	8	140-1494	17	146-0419	15
102-1275	12	112-0229	8	140-1496	17	146-0419	19
103-0408	9	113-0189	8	140-1502	15	146-0420	18
103-0667	9	113-0189-05	8	140-1503	15	146-0420	19
104-0032	7	113-0189-10	8	140-1504	15	146-0440	17
104-0043	7	113-0189-20	8	140-1520	15	146-0440	19
104-0170	7	113-0189-30	8	140-1521	15	148-0840	15
104-0575	5	113-0189-40	8	140-1522	15	149-0003	10
104-0776	5	114-0240	8	140-1528	15	149-1531	15
104-1331	7	114-0300	8	140-1529	15	149-1705	17
105-0332	6	114-0300-10	8	140-1531	15	149-1828	15
105-0541	6	114-0300-20	8	140-1533	15	149-1828	17
105-0637	6	114-0300-30	8	140-1672	15	150-0075	6
110-0068	5	115-0006	5	140-1711	17	150-0078	6
110-0197	5	115-0006-02	5	140-1719	15	150-0096	10
110-0197-02	5	115-0006-05	5	140-1736	17	150-0629	10
110-0197-05	5	120-0140	11	145-0438	15	150-0630	10
110-0197-10	5	120-0161	11	145-0438	17	150-0639	10
110-0197-25	5	120-0398	11	145-0438	19	150-0678	9
110-0539	5	120-0413	11	145-0521	17	150-1187	9
110-0639	5	120-0491	11	146-0241	17	150-1519	6
110-0892	5	120-0735	5	146-0322	18	150-1520	6
110-0893	5	122-0320	11	146-0322	19	150-1542	9
110-0893	5	122-0321	11	146-0325	19	150-1577	10
110-0904	5	122-0347	11	146-0326	18	150-1612	10
110-1807	5	122-0360	11	146-0326	19	152-0184	23
110-1808	5	122-0645	11	146-0327	18	153-0017	15

Numerical Index

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
153-0017	17	160-1285	21	231-0164	27	332-0556	15
153-0058	17	160-1303	20	232-0596	25	332-0556	17
153-0114	15	160-1303	21	232-0596	27	332-0556	29
153-0114	17	160-1311	21	232-2107	25	332-0699	29
153-0440	15	166-0554	20	232-2586	27	332-0942	29
153-0499	15	166-0588	20	232-2587	27	332-1043	29
153-0539	17	166-0772	20	232-2827	27	332-2099	29
153-0541	17	167-0298	20	234-0362	25	332-2103	29
154-0733	15	167-1602	20	234-0362	27	332-2313	29
154-0733	17	168-0143	5	234-0530	27	336-2378	21
154-0733	18	168-0144	5	234-0664	30	336-3377	11
154-0733	19	201-2405	25	301-4441	29	337-0418	12
154-1446	15	201-2421	25	301-4442	29	337-2055	12
154-1446	17	201-2504	25	301-4545	29	338-0946	25
154-1578	23	201-2524	27	301-4634	29	338-0946	27
154-1725	22	201-2528	27	301-4894	29	338-0947	27
154-1725	23	201-2531	27	301-9011	29	338-0948	27
154-1762	22	201-2573	27	304-0015	25	338-1078	29
154-1762	23	203-0153	25	304-0015	27	338-1082	29
154-1883	23	203-0153	27	304-0580	29	338-1200	29
154-1886	23	204-0110	25	304-0706	25	338-1419	25
154-1947	23	204-0110	27	304-0706	27	338-1419	27
154-1972	23	204-0125	27	305-0383	29	338-1677	29
154-1977	15	205-0090	25	307-1193	30	338-1820	29
154-1977	17	205-0116	27	307-1575	29	338-1852	25
154-2061	23	211-0364	25	307-1617	29	352-0161	29
154-2140	23	211-0365	27	307-2562	29	353-0072	25
154-2143	23	212-0345	25	308-0383	29	353-0072	27
154-2146	23	212-0345	27	308-0788	29	353-0084	25
154-2206	15	212-0352	25	309-0077	13	353-0084	27
154-2206	17	212-0352	27	309-0319	11	357-0030	29
154-2310	22	212-0353	25	312-0051	20	402-0282	12
154-2311	22	212-0353	27	312-0246	21	402-0283	12
154-2425	23	212-0359	25	320-0540	29	402-0290	12
154-2554	23	212-0359	27	321-0146	29	402-0475	25
154-2666	15	212-0360	25	321-0174	29	402-0475	27
155-1234	23	212-0360	27	321-0175	29	402-0477	12
155-1239	23	212-0361	25	323-0400	29	402-0480	12
155-1256	22	212-0361	27	323-0440	29	403-1484	12
155-1258	23	212-1232	25	323-0488	29	502-0002	15
155-1520	23	212-1232	27	323-0500	29	502-0002	17
155-1851	22	214-0095	25	323-1088	29	502-0003	15
155-1851	23	214-0095	27	331-0088	29	502-0003	17
155-1910	23	214-0096	25	332-0142	12	502-0053	11
160-0558	20	214-0096	27	332-0142	29	502-0313	15
160-1150	20	220-1818	25	332-0254	29	502-0313	17
160-1150	21	220-1820	25	332-0527	15	502-0575	15
160-1151	20	220-1820	27	332-0527	17	503-0103	15
160-1183	21	220-1823	27	332-0529	15	503-0107	23
160-1219	21	231-0164	25	332-0529	17	503-0280	15


Numerical Index

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
503-0280	17	526-0017	7	801-0050	11	850-0040	11
503-0769	15	526-0018	5	802-0022	21	850-0040	13
504-0092	12	526-0021	15	802-0034	21	850-0040	15
508-0015	29	526-0030	12	804-0016	27	850-0040	17
508-0021	29	526-0032	27	804-0017	15	850-0040	21
508-0191	29	526-0038	12	812-0065	29	850-0040	25
508-0208	29	526-0044	27	812-0066	29	850-0040	27
509-0008	9	526-0049	25	812-0087	29	850-0045	15
509-0040	9	526-0049	27	812-0118	25	850-0045	17
509-0041	5	526-0062	15	812-0118	27	850-0045	22
509-0065	21	526-0062	17	812-0156	25	850-0045	23
509-0145	15	526-0063	5	812-0156	27	850-0045	25
509-0145	15	526-0063	10	813-0111	15	850-0045	27
509-0145	17	526-0065	9	815-0046	9	850-0050	5
509-0145	18	526-0065	11	815-0110	15	850-0050	12
509-0168	5	526-0066	11	815-0110	17	850-0050	25
510-0013	9	526-0115	25	815-0194	11	850-0050	27
510-0014	9	526-0115	27	815-0261	13	850-0055	7
510-0015	6	526-0122	5	815-0285	15	850-0055	12
510-0047	25	526-0158	15	815-0285	17	850-0055	25
510-0047	27	526-0195	12	815-0333	27	850-0055	27
515-0001	6	526-0198	12	815-0341	25	850-2005	20
515-0001	7	526-0234	17	815-0341	27	853-0003	29
515-0015	27	526-0286	12	815-0350	27	853-0008	25
515-0227	7	800-0004	10	815-0350	29	853-0008	27
516-0072	5	800-0007	11	815-0358	21	854-0006	29
516-0130	9	800-0010	5	815-0359	15	854-0010	29
516-0141	5	800-0023	15	815-0359	25	856-0006	12
516-0182	27	800-0023	17	815-0359	27	856-0010	12
516-0196	25	800-0026	22	815-0389	18	856-0012	12
516-0196	27	800-0026	23	815-0421	13	856-0016	12
517-0048	5	800-0028	11	815-0470	17	860-0005	29
517-0067	5	800-0028	15	816-0070	15	860-0011	25
517-0120	5	800-0028	17	816-0197	12	860-0011	27
518-0004	10	800-0030	23	816-0206	12	862-0004	12
518-0014	7	800-0032	9	821-0004	17	862-0015	15
518-0056	29	800-0033	15	821-0004	29	862-0015	17
518-0311	8	800-0033	17	821-0008	13	862-0015	23
518-0350	15	800-0034	9	821-0008	15	862-0015	25
518-0350	17	800-0034	17	821-0008	17	862-0015	27
518-0387	17	800-0043	25	821-0008	29	865-0006	17
518-0390	15	800-0043	27	821-0009	15	865-0019	15
518-0452	31	800-0047	12	821-0009	17	870-0053	10
520-0732	25	800-0050	25	821-0009	20	870-0131	10
520-0733	27	800-0050	27	821-0009	30	870-0131	29
520-0781	27	800-0051	5	821-0010	13	870-0203	25
525-0305	31	800-0064	12	821-0010	23	870-0203	27
526-0008	21	800-0082	12	821-0018	12	870-0212	15
526-0009	27	800-0540	5	850-0030	15	870-0221	29
526-0014	12	800-0541	5	850-0030	17	870-0302	8
				850-0030	25	871-0010	25
				850-0030	27	871-0010	27

HARDWARE IDENTIFICATION


Illustrated hardware items are only for identification purposes. All hardware items listed throughout this par catalog are steel SAE grade five (5) or lower (zinc plated with clear chromate dip) unless parts descriptic indicates differently. All dimensions are in inches.

WASHER TYPES




* - Flat washer dimensions given are: Inside Diameter (ID), Outside Diameter (OD) and Thickness (Thk).

BOLT AND SCREW TYPES



L - Measure length between these points.

INTERNAL DRIVE TYPES



Nominal size (fractional diameter or screw number)
Number of threads per inch
Length in inches

1/4-20 x 3/4"

NUT TYPES



SPECIAL PARTS LIST FOR MODEL

4.0 BFA-3CR

SPEC

15000C

FOR STANDARD PARTS REFER TO CATALOG 965-0262

KEY NO.

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-1142-04

PART NO.	QTY	DESCRIPTION	PART NO.	QTY	DESCRIPTION
146-0419	1	Carburetor, Gasoline (For breakdown parts, see Parts Catalog 965-0262)			

SPECIAL PARTS LIST FOR MODEL 4.0 BFA-8R SPEC 15000D
FOR STANDARD PARTS REFER TO CATALOG 965-0262 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BEI
WIRING DIAGRAM NO. 611-1142-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

RV Style Air Cleaner (Plastic)
Gasoline Fuel System

201-2413	1	Armature Assembly (Includes parts marked *)
204-0110	1	*Ring, Collector
203-0153	1	*Commutator
510-0047	1	*Bearing, Ball
338-0947	1	Harness, Wiring - 4 wire
301-4894	1	Cover, Control Box (Includes Schematic)
323-1088	2	Connector, Wire Nut

SPECIAL PARTS LIST FOR MODEL 4.0 BFA-1RSPEC 19486CFOR STANDARD PARTS REFER TO CATALOG 965-0262 KEY NO. _____

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-1142-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
146-0419	1	Carburetor, Gasoline (For breakdown parts, See Parts Catalog 965-0262)			
338-0948	1	Harness Wiring			
301-4894	1	Cover, Control Box			
323-1088	2	Connector, Wire Nut - Control			

SPECIAL PARTS LIST FOR MODEL

4.0 BFA-1R

SPEC

19486D

FOR STANDARD PARTS REFER TO CATALOG

965-0262

KEY NO.

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO.

611-1142-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
RV Style Air Cleaner (Plastic)					
Gasoline Fuel System					
Two-Step Battery Charger,					
Extended Shaft Generator					
338-0948	1	Harness, Wiring - 4 Wire			
301-4894	1	Cover, Control Box (Includes Schematic)			
323-1088	2	Connector, Wire Nut			

SPECIAL PARTS LIST FOR MODEL

4.0BFA-3CR

SPEC

20275C

FOR STANDARD PARTS REFER TO CATALOG

965-9262

KEY NO.

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO.

611-1142-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

		Right Vacu Flo Exhaust (90°)			
		Extended Shaft Generator			
		RV Style Air Cleaner (plastic)			
		Gasoline Fuel System			

PARTS NOT FURNISHED BY CNAN
Exhaust Heat Shields

Dated 11/19/84

Revised

Page 1 of 1

SPECIAL PARTS LIST FOR MODEL 4.0 BFA-5DR SPEC 22540C
FOR STANDARD PARTS REFER TO CATALOG 965-0262 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 606-0205

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

MANUFACTURED FOR: GENERAL CABLE

RV Style Air Cleaner (plastic)
Gasoline Fuel System
Cross-over Muffler With Spark Arrestor
Valve Stem Oil Seals-Intake
Air Cleaner Wrapper
Two-Step Battery Charger

234-0664	1	Bracket, Fuel Pump, Coil and Start Solenoid.
----------	---	---

PARTS NOT FURNISHED BY OHAN

Control Assembly

SPECIAL PARTS LIST FOR MODEL 4.0 BEA-5DRSPEC 22541C

FOR STANDARD PARTS REFER TO CATALOG

965-0262KEY NO.

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 606-0220

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
MANUFACTURED FOR: GENERAL CABLE					
Industrial Style Air Cleaner					
Gasoline Fuel System					
Exhaust Manifold, Left Hand Down					
Extended Shaft Generator					
Valve Stem Oil Seals-Intake					
Two-Step Battery Charger					
Air Cleaner Wrapper					
234-0664	1	Bracket, Fuel Pump, Coil and Start Solenoid			
Parts Not Furnished By Onan					
Exhaust Heat Shields					
Mounting Plate					
Control Assembly					

Dated 11/19/84Revised Page 1of 1

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

Exhaust Heat Shields

SPECIAL PARTS LIST FOR MODEL 4.0 BFA - 3CR SPEC 25505C
FOR STANDARD PARTS REFER TO CATALOG 965-0262 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-1142-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

MANUFACTURED FOR: TIME MANUFACTURING

RV Style Air Cleaner (plastic)
Gasoline Fuel System
Valve Stem Oil Seals-Intake
Extended Shaft Generator
Air Cleaner Wrapper

PARTS NOT FURNISHED BY ONAN

Exhaust Heat Shields

Dated 11/19/84

Revised

Page 1 of 1

SPECIAL PARTS LIST FOR MODEL 4.0BFA-3CR SPEC 25998C
FOR STANDARD PARTS REFER TO CATALOG 965-0262 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-1142-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

		RV Style Air Cleaner (plastic)			
		LP Vapor Fuel System			
		Right Vacu Flo Exhaust (90°)			
		Spark Arrestor Muffler			
		Extended Shaft Generator			
		Two-Step Battery Charger			
		Valve Stem Oil Seals-Intake			

PARTS NOT FURNISHED BY ONAN

Exhaust Heat Shields

Dated

Revised 11/19/84

Page 1

of 1

SPECIAL PARTS LIST FOR MODEL 4.0BFA-3CR SPEC 26651C

FOR STANDARD PARTS REFER TO CATALOG 965-0262 KEY NO. _____

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-1142-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

Valve Stem Oil Seals-Intake
RV Style Air Cleaner (Plastic)
Gasoline Fuel System
Left Vacu Flo Exhaust (270°)

PARTS NOT FURNISHED BY OEM

Exhaust Heat Shields

Dated 11/20/84

Revised _____

Page 1

of 1

WIRING DIAGRAM NO. 611-1171-03

Dated 11/20/84 Revised Page 1 of 1

SPECIAL PARTS LIST FOR MODEL 4.0 BFA-5DR

SPEC 26927C

FOR STANDARD PARTS REFER TO CATALOG

965-0262

KEY NO.

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO.

611-1142-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

Industrial Style Air Cleaner
Gasoline Fuel System
Valve Stem Oil Seals-Intake
Exhaust Manifold, Left Hand Down
Extended Shaft Generator
Air Cleaner Wrapper

PARTS NOT FURNISHED BY ONAN

Exhaust Heat Shields
Mounting Plate

Dated 11/20/84

Revised

Page 1 of 1

SPECIAL PARTS LIST FOR MODEL 4.0 BFA - 5DR SPEC 27614C
FOR STANDARD PARTS REFER TO CATALOG 965-0262 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-1142-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

MANUFACTURED FOR: TIME MANUFACTURING

RV Style Air Cleaner (Plastic)
Gasoline Fuel System
Extended Shaft Generator
Two-Step Battery Charger
Air Cleaner Wrapper
Valve Stem Oil Seals-Intake

Parts Not Furnished by Onan

Exhaust Heat Shields

Dated 11/20/84 Revised Page 1 of 1

SPECIAL PARTS LIST FOR MODEL 4.0 BFA-5DRSPEC 27036CFOR STANDARD PARTS REFER TO CATALOG 965-0262

KEY NO. _____

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. _____

611-1170-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

MANUFACTURED FOR: GEN CABLE

RV Style Air Cleaner (plastic)

Gasoline Fuel System

Valve Stem Oil Seals-Intake

Extended Shaft Generator

Control With Key Operated Ignition Switch

Two-Step Battery Charger

Air Cleaner Wrapper

Spark Arrestor Muffler

Parts Not Furnished By Onan

Exhaust Heat Shields

Dated _____

11/29/84

Revised _____

Page 1of 1

SPECIAL PARTS LIST FOR MODEL 4.0 BFA-3CR

SPEC 27318C

FOR STANDARD PARTS REFER TO CATALOG 265-0262

KEY NO.

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-1142-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

		RV Style Air Cleaner(plastic)			
		Gasoline Fuel System			
		Left Vacu Flo Exhaust (270°)			
		Valve Stem Oil Seals-Intake			

Dated 11/20/84

Revised

Page 1

of 1

SPECIAL PARTS LIST FOR MODEL 4.0 BPA-5DR

SPEQ 27696C

FOR STANDARD PARTS REFER TO CATALOG 965-0262 KEY NO.

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 511-1142-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

MANUFACTURED FOR: PACIFIC BELL

RV Style Air Cleaner (Plastic)
Gasoline Fuel System
Exhaust Manifold, Left Hand Down
Extended Shaft Generator
Valve Stem Oil Seals-Intake
Two-Step Battery Charger
Air Cleaner Wrapper

Parts Not Furnished By Onan

Exhaust Heat Shields

Dated 11/27/84

Revised

Page 1 of 1

SPECIAL PARTS LIST FOR MODEL 4.0 BEA-3CR SPEC 28530C
FOR STANDARD PARTS REFER TO CATALOG 965-0262 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-1171-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

RV Style Air Cleaner (Plastic)
Gasoline Fuel System
Two-Step Battery Charger

338-1852	1	Harness, Wiring - 4 Wire			
323-1088	3	Connector, Wire Ndt			
152-0184	1	Spacer, Heat Shield Mounting			